



SWIFT. SILENT. SECURE.

# POWER-POLE ANCHOR PRIMING INSTRUCTIONS

**STEP 1** Connect power to the HPU.

**STEP 2** Manually place the Power-Pole Anchor in the deployed position.

**STEP 3** Using the Wireless Dash Switch set to **SLOW** speed, hold the **DOWN** button until the **RED LED** on the dash switch stops flashing and the pump stops running. (Approximately 20 sec.) Repeat this process two more times.

**NOTICE:** The HPU will make a high-pitched whining sound while priming until the air has dissipated from the hydraulic fluid.

**STEP 4** Check the fluid level in the reservoir and add if necessary.

**STEP 5** Hold the **UP** button until the **RED LED** on the Dash Switch stops flashing and the pump stops running. (Approximately 20 sec.) Repeat this process two more times or until the Power-Pole Anchor is fully retracted.

**STEP 6** With the Power-Pole Anchor retracted, hold the **DOWN** button until the **RED LED** on the Dash Switch stops flashing and the pump stops running. Then hold the **UP** button until the **RED LED** on the Dash Switch stops flashing and the pump stops running. Repeat this step once.

**STEP 7** Set the Dash Switch to **MEDIUM** speed.

**STEP 8** Hold the **DOWN** button until the **RED LED** on the Dash Switch stops flashing and the pump stops running. Then hold the **UP** button until the **RED LED** on the Dash Switch stops flashing and the pump stops running. Repeat this step once.

**STEP 9** With the Power-Pole Anchor fully retracted, manually apply a force to attempt to deploy the Power-Pole Anchor. If the Power-Pole Anchor does not stay in the retracted state, repeat **STEP 8** until it does.

**STEP 10** Once on the water, navigate to an area that is deep enough to fully deploy the Power-Pole Anchor without it touching the bottom.

**STEP 11** Using the Dash Switch set to **MEDIUM** speed, fully deploy and retract the Power-Pole Anchor **six** times.

**STEP 12** Your Power-Pole Anchor should be completely primed at this point, but if you suspect it isn't, repeat **STEP 11** until it is or contact JL Marine System's Inc. for Technical Support at 813-689-9932 Option 2

Need help? Contact our Customer Service Team at **1 + 813.689.9932 Option 2**



9010 Palm River Road, Tampa, Florida 33619  
phone 813.689.9932 • fax 813.689.8883 • power-pole.com  
©2021 all rights reserved. Power-Pole Shallow Water Anchor